

Polyester transparency film for photo-realistic illuminated displays and highest quality backlit applications



Clear and backlit film

## euromedia Blazing Backlit wb

Unmatched frontprint-backlit for HP etc. Innovative product solution for use with water-based pigment ink. Fulfils all requirements perfectly: non-reflective, matt white Blazing Backlit wb is just as impressive when purely frontlit as well as backlit thanks to its outstanding light diffusion properties.

Fulfils all requirements perfectly: Non-reflection, matt white Blazing Backlit is just as impressive purely when frontlit as it is when backlit. Scratch-resistant, impermeable coating. Perfect for outside and in. Ultra fast drying vibrant prints within your grasp, giving you saturated colours, not only when viewed backlit, that will make your customers light up. If you require the flexibility of using dye and pigmented ink and also need B1 certification, euromedia Universal Backprint Film FR would be just the right choice for you.

### Dimensions

216mic - 1270mm(50') - 30,5m  
 216mic - 1370mm(54') - 30,5m  
 216mic - 1524mm(60') - 30,5m

### Product Code

70100098684  
 70100098632  
 70100098708



### Hints & Tips

Blazing Backlit wb is a 100% premium product for best performance, it is usually worth creating an individual profile

## euromedia Blazing Backlit wb

### Product Properties

#### Applications

- indoor
- outdoor
- displays
- citylights/backlights
- trade fairs
- photo-quality printing

#### Properties

- PVC-Free
- backlit/translucent
- cold lamination
- water-resistant (with pigmented ink)

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The film should ideally be processed and stored in an environment of 30 to 65% relative humidity at a temperature of 10 to 35 C. Store in the original packaging (cardboard box and PE bag). We recommend wearing cotton gloves when handling inkjet coated materials, in order to avoid fingerprints.



#### Specifications

Material	Polyester
Ink	Waterbased inks
Gloss Level	Matt
Whiteness	>102%
Total thickness	216 mic
Opacity	80%
Shelf life	Up to 1 year

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
 Heesenstraße 31 40549 Düsseldorf DE  
 Tel: +49 211-5089-326  
 Fax: +49 211-5089-287  
 grafische\_systeme@fujifilm.de