

Ultra clear monomeric vinyl for  
shop windows, glass doors,  
indoor and shortterm outdoor  
transparent surfaces



Clear and backlit film

## euromedia Clear Vinyl sticky wb

The perfect solution for self-adhesive, transparent graphics produced with water-based printing. A particularly unique feature of this euromedia product is its incomparable printability: correctly dried, even pigmented inks look crisp and brilliant.

Deep black, saturated colours photorealistic on transparent the whole thing fast drying and soon ready for further processing. Graphics on euromedia Clear Vinyl sticky wb are very durable, and even the highly transparent adhesive remains highly transparent. It is also semi-permanent, allowing easy removal of the print again after use. If you're looking for a top class material, which is highly transparent, but not self-adhesive, just try out some euromedia Cleafilm!.

### Dimensions

100mic - 0914mm(36") - 20m  
100mic - 1067mm(42") - 20m

### Product Code

70100098139  
70100098220



### Hints & Tips

We recommend that you wear ordinary cotton gloves when handling the material. This will offer the material and graphics the best protection against undesirable finger prints. Apply self-adhesive materials in general at an ambient temperature of at least 8 -10°C. This will allow it to adhere fast, last for a long time and not let you down

## euromedia Clear Vinyl sticky wb

### Product Properties

#### Applications

- indoor
- displays
- 2D wraps
- trade fairs
- photo-quality printing
- outdoor

#### Properties

- transparent
- cold lamination
- semi-permanent adhesive
- water-resistant (with pigmented ink)
- backlit/translucent

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

Material	Monomeric Vinyl
Ink	Waterbased inks
Gloss Level	Glossy
Total thickness	260 mic
Liner	145 mic
Adhesive type	Polyacrylat Dispersion
Adhesive strength	~ 5/25 N/mm (A.F.E.R.A) after 24h: ~ 10/25 N/mm (A.F.E.R.A)

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
Heesenstraße 31 40549 Düsseldorf DE  
Tel: +49 211-5089-326  
Fax: +49 211-5089-287  
grafische\_systeme@fujifilm.de