

Highly transparent polyester film  
for backlits, motion displays,  
indoor and outdoor displays



Clear and backlit film

## euromedia Clear Film

Clearly the best solution for the production of high quality transparent graphics using solvent-based printers. Exciting images appear on the glossy surface – real eyecatchers!.

Beautiful effect, robust feel, easy handling: Clear Film not only looks good, it can also be assembled cleanly and problem-free (antistatic reverse side!). As a 100% polyester substrate, it is completely dimensionally stable, non-split and heat resistant. For something identical in appearance, but with the extra feature of being self-adhesive, there is also euromedia GlasDeco clear!.

### Dimensions

195g - 1372mm(54') - 30m, PSO

### Product Code

70100098437



### Hints & Tips

In general, inks dry more slowly on polyester. Make sure, therefore, that you give it sufficient drying, roll-up the graphics for transport or store as 'loosely' as possible

## euromedia Clear Film

### Product Properties

#### Applications

- indoor
- displays
- citylights/backlights
- art
- trade fairs

#### Properties

- PVC-Free
- cold cutting
- transparent

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

The melting point is 250°C.

#### Storage

The product should be stored in its original packaging at a room temperature of 10°C - 20°C and 20% - 55% relative humidity.



#### Specifications

Material	Polyester
Ink	Solvent, UV
Gloss Level	Glossy
Thickness	142 mic
Weight	195 g/m <sup>2</sup>
Tensile strength	MD 17 KgF / mm <sup>2</sup> TD 10 KgF / mm <sup>2</sup> (ASTM D882-83)
Application temperature	10°C to 30°C; 30 - 65% RH
Others	Light transmission: >90%
Shelf life	2 years

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
Heesenstraße 31 40549 Düsseldorf DE  
Tel: +49 211-5089-326  
Fax: +49 211-5089-287  
grafische\_systeme@fujifilm.de