

For backlit applications such as
lightboxes and for point of sale
designs



Clear and backlit film

euromedia Color Backlit

euromedia Color Backlit is the perfect product for small and large jobs for backlit applications. The robust 200 mic. thick film is compatible with all common solvent, latex and UV ink systems. The satin gloss surface ensures high colour density. Backlit or not, Color Backlit will catch everyone's attention.

In addition to its excellent colour brightness euromedia Color Backlit is also exceptionally robust: The scratch-resistant surface and outstanding lie-flat properties make on-site mounting simple and secure.

Dimensions

200mic - 0914mm(36') - 30m, PSO
200mic - 1067mm(42') - 30m; PSO
200mic - 1372mm(54') - 30m; PSO
200mic - 1524mm(60') - 30m; PSO

Product Code

70100109194
70100109168
70100109227
70100109358



Hints & Tips

Color Backlit has been specially designed for backlit applications. If you bear this in mind when setting up your printer and evaluate the print when backlit instead of frontlit, you can be sure of producing high strength eye-catching prints using euromedia Color Backlit

euromedia Color Backlit

Product Properties

Applications

- indoor
- outdoor
- citylights/backlights

Properties

- PVC-Free
- backlit/translucent

Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



Specifications

Material	Polyester film
Ink	Solvent, Latex, UV
Gloss Level	Satin matte
Whiteness	L* 85 a* 0 b* -7.0
Thickness	200 mic
Weight	285 g/m ²
Temperature resistency	up to 90°C
Shelf life	Up to 1 year

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
Heesenstraße 31 40549 Düsseldorf DE
Tel: +49 211-5089-326
Fax: +49 211-5089-287
grafische_systeme@fujifilm.de