

It can be used on flat surfaces for short to intermediate term indoor and outdoor applications such as window advertising and glass decoration.



Clear and backlit film

euromedia Competition Vinyl transparent

Competition Vinyl transparent is a monomeric transparent PVC film suitable for applying to flat surfaces such as glass. With Competition Vinyl transparent your advertising messages are always clear to read, no matter if it's at the point of sale or in window advertising. The glossy surface guarantees the reproduction of brilliant colours for solvent, latex or UV inks. The adhesive is transparent and removable. Competition Vinyl transparent can be used for short to intermediate term indoor and outdoor applications up to 2 years. .

Do you need a material for slightly curved glass underground, choose euromedia Polymer transparent. When you look for a crystal clear film for longterm applications, we recommend euromedia GlasDeco clear.

Dimensions
80mic - 1520mm(60') - 50m

Product Code
70100112225



Hints & Tips

We basically recommend that the print is left to dry out for 24 hours before finishing. To finish Glass Deco Vinyl standard with a laminate, it can be used the euromedia Ultra HighProtection Laminate gloss. During the application process itself, however, we recommend an ambient temperature of at least 10°C.

euromedia Competition Vinyl transparent

Product Properties

Applications

- indoor
- outdoor
- trade fairs

Properties

- removable adhesive
- monomeric vinyl

Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



Specifications

Material	Monomeric PVC
Ink	Solvent, Latex, UV
Gloss Level	Glossy
Thickness	80 mic
Liner/ Backing weight	135 g/m ²
Adhesive type	Polyacrylate
Adhesive strength	7N / 25mm
Temperature resistency	-40°C to 80°C
Others	Water resistance: after 48h/23°C

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
 Heesenstraße 31 40549 Düsseldorf DE
 Tel: +49 211-5089-326
 Fax: +49 211-5089-287
 grafische_systeme@fujifilm.de