

Indoor and particularly outdoor  
backlit applications, lightboxes,  
citylights



Clear and backlit film

## euromedia Outdoor Backlit wb

Polyester film for printing with pigmented water-based inks (e.g. HP DesignJet, HP Z series). A high quality backlit media of 170mic thickness, particularly designed for outdoor applications.

The snow white euromedia coating gives a homogeneous printed image with good frontlit and very good backlit properties, particularly with pigmented ink HP5000/5500 UV. In combination with this ink the material exhibits optimum water and wipe resistance.

### Dimensions

170mic - 0914mm(36') - 30,5m  
170mic - 1067mm(42') - 30,5m  
170mic - 1370mm(54') - 30,5m  
170mic - 1520mm(60') - 30,5m

### Product Code

70100098167  
70100098162  
70100098169  
70100098164



### Hints & Tips

To be able to realistically assess the print, also test if possible with backlighting. The matt front side is printed, right-reading (frontprint)

## euromedia Outdoor Backlit wb

### Product Properties

#### Applications

- indoor
- outdoor
- displays
- citylights/backlights
- trade fairs
- photo-quality printing

#### Properties

- PVC-Free
- backlit/translucent
- cold lamination
- water-resistant (with pigmented ink)

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

Material	Polyester
Ink	Waterbased inks
Total thickness	170 mic
Weight	205 g/m <sup>2</sup>
Outdoor durability	Laminated up to 1 year, without laminate up to 3 months

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
 Heesenstraße 31 40549 Düsseldorf DE  
 Tel: +49 211-5089-326  
 Fax: +49 211-5089-287  
 grafische\_systeme@fujifilm.de