

Robust, satin matt polyester film with a gloss silver back for indoor and short-term outdoor popups. Suitable for solvent, latex and UV inks



Display Films

## euromedia PopUp Film Advanced

The robust euromedia PopUp Film Advanced with a satin matt coating and gloss silver back has been designed for use in popup systems. The approx. 290 micron thick polyester film reproduces excellent print quality with brilliant colours. Its satin matt surface guarantees photorealistic print and colour reproduction without annoying reflections. The gloss silver, scratch-resistant back rounds off the high quality appearance and gives the material 100% opacity.

euromedia PopUp Film Advanced also has excellent lie-flat properties in use. A special non-slip coating on the back ensures trouble-free printing. Do you need a high quality, totally scratch-resistant popup film for demanding long-term applications? If so, have a look at our PopUp Film Premium suitable for solvent, latex and UV inks. Are you looking for a flame-retardant, B1-certified popup film for short-term use and with a good price-performance ratio? If so, use euromedia PopUp Film Standard in the version for solvent and UV inks or for water-based dye-based and pigmented inks.

### Dimensions

290mic - 0914mm(36') - 20m  
 290mic - 1067mm(42') - 20m  
 290mic - 1270mm(50') - 20m

### Product Code

70100112196  
 70100112194  
 70100112195



### Hints & Tips

Finish PopUp Film Advanced for an even higher quality look and best mechanical protection using Ultra HighProtection gloss, matt or crystal sand laminate. Roll up loosely with the print side facing outwards for transport. This will keep the whole graphics including the laminate intact

## euromedia PopUp Film Advanced

### Product Properties

#### Applications

- indoor
- outdoor
- displays
- trade fairs

#### Properties

- PVC-Free
- Blockout

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

Material	Polyester
Ink	Solvent, Eco-Solvent, Latex, UV
Gloss Level	Satin matt
Back	Silver glossy
Thickness	290 mic
Weight	405 g/m <sup>2</sup>

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
 Heesenstraße 31 40549 Düsseldorf DE  
 Tel: +49 211-5089-326  
 Fax: +49 211-5089-287  
 grafische\_systeme@fujifilm.de