

Particularly easy to apply 5-year
vinyl for flat and slightly curved
indoor and outdoor surfaces



Self-Adhesive outdoor

euromedia 2D SmartApply

The versatility of euromedia 2D SmartApply is impressive. The self-adhesive, calendared 5-year polymeric film can be used for a large number of high quality solvent, latex and UV printing applications and is particularly suitable for applying to flat and slightly curved surfaces. The grey adhesive reliably obliterates even high contrast surfaces. Excellent lie-flat properties allow problem-free printing and finishing. Thanks to its innovative air channel technology euromedia 2D SmartApply is very easy to apply without bubbles, which means it can be handled without problems even by inexperienced users. The particularly white, glossy surface guarantees reproduction of bright colours and excellent contrast.

euromedia 2D SmartApply is very dimensionally stable, even over long periods of time and under adverse conditions. For application professionals, who do not require a film to have air channels, we recommend the universal 5-year polymeric euromedia 2D Vinyl P-GB. For short-term applications we advise you to use monomeric euromedia vinyls.

Watch our video about the 2D Smart Apply here

Dimensions

75mic - 1067mm(42') - 45,7m
75mic - 1370mm(54') - 45,7m
75mic - 1524mm(60') - 45,7m

Product Code

70100109520
70100109455
70100109514



Hints & Tips

An application using 2D SmartApply even looks even better, if you finish and protect the graphics with a cold laminate. We recommend euromedia 2D Laminate for finishing.

euromedia 2D SmartApply

Product Properties

Applications

- indoor
- outdoor
- 2D wraps
- trade fairs
- 3-5 years durability

Properties

- permanent adhesive
- polymeric vinyl
- Blockout

Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

Apply on clean and dry surfaces only.

The material is removeable without any residues.

Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.

It shouldn't be exposed to direct sunlight.



Specifications

Material	Polymeric PVC, calendered
Ink	Solvent, Latex, UV
Surface	White
Gloss Level	Glossy
Thickness	75 mic
Tensile strength	>2,3 kg/cm
Adhesive type	Solvent based (grey)
Adhesive strength	2.5 lbs/in; 0.45 kg/cm
Release value	13.78 g/cm (90°; 760 cm/min)
Temperature resistency	-29°C to 65°C
Application temperature	10°C to 32°C
Others	Dimensional stability: 0,63
Shelf life	1 year

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
Heesenstraße 31 40549 Düsseldorf DE
Tel: +49 211-5089-326
Fax: +49 211-5089-287
grafische_systeme@fujifilm.de