

Universal 5-year vinyl with grey adhesive for flat and slightly curved indoor and outdoor surfaces



Self-Adhesive outdoor

## euromedia 2D Vinyl P-GB

The versatility of euromedia 2D Vinyl P-GB is impressive. The self-adhesive, calendared 5-year polymeric film can be used for a large number of high quality solvent and UV printing applications and is particularly suitable for applying to flat and slightly curved surfaces. The grey adhesive reliably obliterates even high contrast surfaces. Excellent lie-flat properties allow problem-free printing and finishing. The particularly white, glossy surface guarantees reproduction of bright colours and excellent contrast.

euromedia 2D Vinyl P-GB is very dimensionally stable, even over long periods of time and under adverse conditions. If you prefer a material that is particularly easy to apply and reliably obliterates even high contrast surfaces, we recommend euromedia 2D SmartApply. For short-term applications we advise you to use monomeric euromedia vinyls

Watch our video about the 2D Vinyl P-GB here

### Dimensions

75 mic - 1067 mm(42') - 50m

75 mic - 1370mm(54') - 50m

75 mic - 1520mm(60') - 50m

### Product Code

70100112174

70100112175

70100112176

## euromedia 2D Vinyl P-GB

### Product Properties

#### Applications

- indoor
- outdoor
- 2D wraps
- trade fairs
- 3-5 years durability

#### Properties

- permanent adhesive
- polymeric vinyl
- Blockout

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

Material	Polymeric PVC
Ink	Solvent, Latex, UV
Gloss Level	Glossy
Thickness	75 mic
Tensile strength	>2,3 kg/cm
Adhesive type	Solvent based (grey)
Adhesive strength	2.5 lbs/in; 0.45 kg/cm
Release value	39 g/cm (90°; 760 cm/min)
Temperature resistency	-29°C to 65°C
Application temperature	16°C to 32°C
Others	Dimension stability: 0.63 mm

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
Heesenstraße 31 40549 Düsseldorf DE  
Tel: +49 211-5089-326  
Fax: +49 211-5089-287  
grafische\_systeme@fujifilm.de