

Self-adhesive vinyl with one-way transparency, B1/ M1 for window graphics on vehicles or busses, display windows, trade fairs



Self-Adhesive outdoor

euromedia InSightOut Vinyl FR

High-quality polymeric film with black reverse side shows very dimensional stability and is an all-purpose vinyl suitable for solvent-, UV or latex applications. Due to its 50:50 perforation, InSightOut Vinyl FR makes for unrestricted viewing from the inside out when mounted onto transparent surfaces. Safe one-way vision is ensured by high-precision production and perforation technology to a precision grade of 1/1000 mm. In addition, prints win over with fine detail and highly satisfactory close-up views. This polymeric film comes up trumps with convincing, long-lasting durability and a semi-permanent adhesive allowing problem-free mounting and removal of film. In its design certification for motor vehicles according to road traffic licensing regulations (ABG: Allgemeine Bauartgenehmigung nach 22a Straßenverkehrs-Zulassungs-Ordnung ZtVZO), the German Federal Motor Transport Authority has approved InSightOut Vinyl FR even when used in combination with cast InSightOut Laminate.

The reverse side of InSightOut Vinyl FR is not just tinted black but constitutes a separate black layer. InSightOut Vinyl FR can therefore be removed without leaving any residue or black adhesive marks. To top it all: InSightOut Vinyl FR is the only B1 and M1 certified window graphics film – your safe choice for all of Europe when pasting in areas or locations with heightened fire protection requirements (airports, public spaces, trade fairs etc.). Keen to apply a privacy shield on your windows? Have a go with our Silver Sand effect vinyl! A semi-transparent self-adhesive vinyl with slight silvery special effect; it can be used as a decorative application, for coverage of larger surfaces or as privacy guard. In need of cost effective alternatives for medium term window graphics without approval for public transport or B1 certification? Then try our euromedia OneWayVision!.

Dimensions

120mic - 1370mm(54') - 25m

Product Code

70100098230



Hints & Tips

We recommend that you apply euromedia InSightOut Vinyl together with the respective euromedia InSightOut Laminate. Not strictly necessary if required to adhere to road traffic licensing regulations, but facilitates easy run-off of rainwater and dirt and comes with long lasting and high impact InSightOut-effect.

euromedia InSightOut Vinyl FR

Product Properties

Applications

- indoor
- outdoor
- 2D wraps
- trade fairs

Properties

- semi-permanent adhesive
- fire classification B1
- fire classification M1
- polymeric vinyl

Processing Tips

Occasionally rolls may contain joins, which unfortunately cannot be avoided due to technical reasons. The join has no effect on the quality or handling and processing of the rolls. Both the rolls and the join are clearly marked and cannot form the subject of any claim.

The material may be used for slightly curved rear windows. We recommend that you test the material fully before use.

Prevent from contact with solvent or ammonia based cleaner. Clean window with soap and water. Rinse and dry glass after cleaning. Always clean and dry surface before application.

We basically recommend that the print is left to dry out for 24 hours before finishing.

Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



Specifications

Material	Polymeric PVC
Ink	Solvent, Latex, UV
Flame retardancy	B1, M1
Back	Black
Thickness	120 mic
Adhesive strength	Semi-permanent, removable up to 1 year (up to 6 months without any residues)
Adhesive type	Transparent, solvent based acrylic adhesive
Temperature resistency	-17 C°
Application temperature	+10°C to +32°C
Outdoor durability	Up to 1 year
Others	Perforation Ratio (%): 50 Perforation Ratio (mm): 1,5

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
Heesenstraße 31 40549 Düsseldorf DE
Tel: +49 211-5089-326
Fax: +49 211-5089-287
grafische_systeme@fujifilm.de