

Selfadhesive vinyl for
photorealistic reproductions.
Suitable for waterbased pigment
inks.



Self-Adhesive outdoor

euromedia Photo Vinyl II wb

euromedia PhotoVinyl II wb is a selfadhesive, monomeric vinyl with glossy finish suitable for photorealistic reproductions. The special coating has a perfect ink trapping which creates brilliant colours and high density in a low drying time. The material with approximately 130 mic and permanent adhesive is very easy to apply on flat surfaces.

Photo Vinyl II wb can be used for various indoor as well as for short term outdoor applications.

Dimensions

130mic - 0914mm(36') - 30m
130mic - 1067mm(42') - 30m
130mic - 1370mm(54') - 30m
130mic - 1524mm(60') - 30m

Product Code

70100111243
70100111245
70100111244
70100111246



Hints & Tips

The material is also suitable for waterbased dye inks. A protective laminate from the euromedia series, like for example euromedia MonoLam Laminate gloss, can further enhance the optical effect and also improve the mechanical stability.

euromedia Photo Vinyl II wb

Product Properties

Applications

- indoor
- outdoor
- photo-quality printing
- application on flat surfaces



Properties

- monomeric vinyl
- permanent adhesive
- water-resistant (with pigmented ink)
- cold lamination

Processing Tips

The surface where the vinyl will be applied needs to be clean, dry and greaseless. The recommended application temperature is between 15 - 25°C.

Subjects of ABS (Acrylnitril-Butadien-Styrol), PVC, Polystyrol, Polycarbonat, Polyamid, as well as acrylic coated surfaces are non-recommended surfaces in combination with Photo Vinyl II wb.

Disassembling: The recommended temperature for disassembling is 15 - 25° C. Slight residues can be removed with soap water or clear benzine. It is recommended to test the surface upfront.

Storage

The product should be stored in its original packaging at a room temperature of 10°C - 25°C and 25 - 65% relative humidity.

Specifications

Material	Monomeric PVC
Ink	Waterbased inks
Thickness	130 mic
Total thickness	270 mic (with Liner)
Liner	Paper
Adhesive type	Permanent
Adhesive strength	14 N/25mm (>24h)

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
 Heesenstraße 31 40549 Düsseldorf DE
 Tel: +49 211-5089-326
 Fax: +49 211-5089-287
 grafische_systeme@fujifilm.de