

Self-adhesive vinyl for construction signs, information boards, print & cut designs, and outdoor markings



Self-Adhesive outdoor

euromedia Power Vinyl gloss

Specially developed for sign making with solvent printers and cutter plotters. Grey adhesive behind (100% opaque), and the ultra white, glossy coating offers high quality printability.

Additional added value is provided by features such as: - grey adhesive, which gives full opacity. No show through of the underlying graphics or coatings. - 120 micron material thickness. Power Vinyl is easy to handle, which makes it very simple to apply without distortion. - Repositionable. If it doesn't go according to plan at the first attempt the material is very easy to peel off and reposition. For applications over domed shapes or through grooves etc - e.g. for partial vehicle wraps, we recommend a polymeric vinyl such as euromedia 2D SmartApply; 2D Laminate gloss/matt provides a suitable finish.

Dimensions

120mic - 0760mm(30') - 50m
120mic - 1067mm(42') - 50m
120mic - 1370mm(54') - 50m
120mic - 1520mm(60') - 50m

Product Code

70100098507
70100098963
70100110054
70100110047



Hints & Tips

Our basic recommendation is to let the print solvents fully evaporate completely before finishing with a laminate or varnish. If you are unable to lay the whole print out due to lack of space, just stand the prints on end, loosely rolled. The important thing is that the solvents have time and space to fully evaporate then you can be sure of bubble-free application

euromedia Power Vinyl gloss

Product Properties

Applications

- indoor
- outdoor
- trade fairs
- 1-3 years durability

Properties

- semi-permanent adhesive
- Blockout
- monomeric vinyl

Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



Specifications

| | |
|------------------------|--------------------|
| Material | Monomeric Vinyl |
| Ink | Solvent, Latex, UV |
| Gloss Level | Glossy |
| Thickness | 0,12 mm |
| Temperature resistency | -50°C to 80°C |
| Outdoor durability | 1 to 3 years |
| Others | Double PE coating |
| Shelf life | Up to 1 year |

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
Heesenstraße 31 40549 Düsseldorf DE
Tel: +49 211-5089-326
Fax: +49 211-5089-287
grafische_systeme@fujifilm.de