

Semi-transparent, SA vinyl, slight silver effect for durable indoor and outdoor decorative, partition and large area coverings



Self-Adhesive outdoor

## euromedia SilverSandEffect Vinyl

Exclusive polymeric vinyl with a smart sand-blasted effect for innovative SA designs using solvent printing. Unequaled depth of colour and vibrant image quality on the slightly silver glistening surface.

euromedia SilverSandEffect Vinyl runs perfectly through the printer, its 80 micron thickness allows easy application and means highly durable, high quality as well as low cost applications in the growth market of interior design etc. If, on the other hand, you're looking for a highly transparent SA media, we recommend euromedia Glas Deco Clear!.

### Dimensions

80mic - 1370mm(54') - 50m

80mic - 1525mm(60') - 50m

### Product Code

70100098583

70100098545



### Hints & Tips

To achieve the best print result, it is worth profiling the film. Allow yourself sufficient time for the print to dry and the solvent to evaporate. If you are printing roll to roll, unroll the web as soon as possible again after printing. The best thing is to then lay it out flat, or at least loosely rolled up on the reel core

## euromedia SilverSandEffect Vinyl

### Product Properties

#### Applications

- indoor
- outdoor
- citylights/backlights
- 2D wraps

#### Properties

- permanent adhesive
- backlit/translucent

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

Material	Polymeric calendered PVC
Ink	Solvent, Latex
Gloss Level	Crystal-sand (silver coloured)
Total thickness	80 mic
Tack	15 N/25mm
Adhesive strength	18 N/25mm
Outdoor durability	Up to 7 years

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
 Heesenstraße 31 40549 Düsseldorf DE  
 Tel: +49 211-5089-326  
 Fax: +49 211-5089-287  
 grafische\_systeme@fujifilm.de