

For short and medium-term applications on streets, pavements, car parks or tarmac areas



Self-Adhesive outdoor

euromedia Street Vinyl

The white gloss film has been designed for use in combination with euromedia Street Laminate on rough indoor and outdoor surfaces. Outdoor durability is up to 6 months, depending on mechanical wear. The self-adhesive sandwich repels snow and rain but is also removable.

Take over the ground as an advertising medium! With a sandwich made of euromedia Street Vinyl and euromedia Street Laminate you can also use rough floor areas as an advertising space. The production combination is ideal for short and medium-term applications incl. on pavements and tarmac areas, where the advertising needs to be removed again rapidly and without leaving a residue. Be impressed by strong colours and deep blacks. The high quality white gloss surface of Street Vinyl allows you to produce a high contrast, brilliant print image and achieves outstanding opacity to counteract show-through of dark backgrounds. The material has a high degree of dimensional stability.

Dimensions

80mic - 1370mm(54') x 25m

Product Code

70100099111



Hints & Tips

euromedia Street Vinyl must be used in combination with euromedia Street Laminate. Because of the wide diversity of surfaces, we recommend applying the film beforehand as a test on the desired surface. The bond on rough surfaces should be encouraged using a fan and damp cloth. The surface should have an application temperature of at least 10-15 degrees Celsius and be dry and free of grease. The Street Laminate must be processed flush with the edges to ensure adhesion to the surface and avoid trip hazards. The film must not be applied to smooth, glazed and polished surfaces. The adhesive strength will increase. For smooth areas we recommend euromedia Mono Vinyl in combination with our euromedia FloorGraphics Laminate

euromedia Street Vinyl

Product Properties

Applications

- indoor
- outdoor
- 1-3 years durability

Properties

- removable adhesive
- cold lamination
- monomeric vinyl

Processing Tips

Street Vinyl must be used in combination with Street Laminate.

Street Laminate must be applied flush with the edges to guarantee adhesion with the surface and avoid trip hazards. We recommend rounding off the corners of the graphics so that they have less area for attack.

On rough surfaces the composite should be applied using a fan and damp cloth. The surface should have an application temperature of at least 10-15 degrees Centigrade and be dry and free of grease.

Street Vinyl must not be applied to smooth, glazed and polished surfaces. (The adhesive strength will increase dramatically.)

Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



Specifications

Ink	Solvent, Latex, UV
Surface	White
Gloss Level	Glossy
Thickness	80 mic
Adhesive type	Polyacrylic adhesive (waterproof)
Adhesive weight	~ 100 g/m ²
Adhesive strength	~ 5/25 N/mm
Temperature resistency	-30 °C to +70 °C
Shelf life	Up to 3 years

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
 Heesenstraße 31 40549 Düsseldorf DE
 Tel: +49 211-5089-326
 Fax: +49 211-5089-287
 grafische_systeme@fujifilm.de