

Indoor/outdoor matt surface  
wrappings, product solution for  
traded fairs etc. straight from the  
printer



Self-Adhesive outdoor

## euromedia WonderVinyl FR wb

Designed for printing with water-based pigmented inks, e.g. DesignJet Z series from HP. The micro porous coating also allows printing with pure dye inks (please note the special instructions with this). If you are laminating (recommendation: HighProtection Laminate) and would like to finish the cut end - no problem: WonderVinyl FR wb won't draw in water. It is also possible to remove up to 3 month later without leaving a residue.

Further processing is unproblematic in every respect, the product sits well in the hand during pasting up. Where the special properties of SOLVENT printing technology are not absolutely essential, you can immediately fall back on this environmentally friendly printable substrate.

### Dimensions

165mic - 0610mm(24') - 20m  
165mic - 0914mm(36') - 20m  
165mic - 1067mm(42') - 20m  
165mic - 1270mm(50') - 20m  
165mic - 1370mm(54') - 20m  
165mic - 1520mm(60') - 20m

### Product Code

70100098369  
70100098960  
70100098342  
70100098349  
70100098341  
70100098385



### Hints & Tips

A protective laminate from the euromedia series can further enhance the optical effect and also improve the mechanical stability. The microporous surface technology allows you to further process the product straight away, e.g. cutting to size and applying. The ink must be completely dry before lamination

## euromedia WonderVinyl FR wb

### Product Properties

#### Applications

- indoor
- outdoor
- displays
- 2D wraps
- trade fairs

#### Properties

- removable adhesive
- fire classification B1
- cold lamination
- water-resistant (with pigmented ink)

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

|                   |                         |
|-------------------|-------------------------|
| Material          | Vinyl film              |
| Ink               | Waterbased inks         |
| Gloss Level       | Matt                    |
| Thickness         | ~ 145 mic               |
| Total thickness   | ~ 310 mic               |
| Tearing Strength  | ~ 7/25 N/mm (A.F.E.R.A) |
| Adhesive type     | Polyacrylat Dispersion  |
| Adhesive strength | ~ 7/25 N/mm (A.F.E.R.A) |

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
 Heesenstraße 31 40549 Düsseldorf DE  
 Tel: +49 211-5089-326  
 Fax: +49 211-5089-287  
 grafische\_systeme@fujifilm.de