

Polymeric, glossy protective laminate for finishing flat and slightly curved surfaces



Protective Films

## euromedia 2D Laminate gloss

euromedia 2D Laminate gloss is specially developed for safe, colourless protection and finishing of high quality, slightly curved applications. It is best for self-adhesive sandwiches with polymeric vinyls (e.g. euromedia 2D SmartApply). euromedia 2D Laminate gloss is highly weather and scratch resistant, therefore making it suitable for reliable long-term outdoor applications. The product is long term dimension stable, also under adverse conditions.

The perfect combination for finishing cast self-adhesive graphics on three-dimensional surfaces, e.g. for car wrapping, is a sandwich made of euromedia 3D SmartApply together with 3D Laminate gloss/matt.

### Dimensions

75mic - 1067mm(42') - 45,7m  
 75mic - 1370mm(54') - 45,7m  
 75mic - 1520mm(60') - 45,7m

### Product Code

70100098029  
 70100110295  
 70100098652



### Hints & Tips

Get an additional boost in adhesion, transparency and brilliance for your print, if you heat the laminating rollers slightly; around 30°C has proven to be effective in this respect

## euromedia 2D Laminate gloss

### Product Properties

#### Applications

- indoor
- outdoor
- 2D wraps
- 3-5 years durability



#### Properties

- permanent adhesive

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

Apply on dry and clean surfaces only.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.

#### Specifications

Material	Polymeric PVC, calendered
Gloss Level	Glossy
Thickness	75 mic
Tearing Strength	1,8 kg/cm (>130 %)
Tack	0,45 kg/cm
Adhesive strength	11/25 N/mm
Release value	47 g/cm
Temperature resistency	-29°C - +65°C
Application temperature	4.4°C to 38°C
Others	Dimension stability: 0.51 mm
Shelf life	1 year

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
 Heesenstraße 31 40549 Düsseldorf DE  
 Tel: +49 211-5089-326  
 Fax: +49 211-5089-287  
 grafische\_systeme@fujifilm.de