

High quality photo prints for posters, billboards and art prints



Photo Papers

euromedia BigPicture Photopaper 200 gloss wb

Make your colour dreams come true with euromedia BigPicture Photopaper 200 gloss wb. This gloss, ultra white high resolution photo paper with a PE coating on both sides is compatible with all water-based inkjet printing systems and inks.

Outstanding suitability for pigmented and dye-based ink. Big Picture papers have a new ink acceptance layer, which allows you to produce a particularly large colour gamut. The opaque white paper has brilliant colour reproduction and very good edge definition. BigPicture Photopaper 200 gloss wb is dry immediately after printing and extremely resistant to finger prints as well as wiping. It is also very stable to environmental influences and has very good lie-flat properties. This makes BigPicture Photopaper 200 gloss wb a truly high quality photo experience in every respect. For exactly the same impressive prints on a thicker material with even greater handling properties, simply choose BigPicture Photopaper 260 gloss wb.

Dimensions

200g - 0610mm(24') - 30m
 200g - 0914mm(36') - 30m
 200g - 1067mm(42') - 30m
 200g - 1270mm(50') - 30m
 200g - 1372mm(54') - 30m
 200g - 1524mm(60') - 30m

Product Code

70100109114
 70100109217
 70100109163
 70100109388
 70100109195
 70100109116



Hints & Tips

By using a protective laminate, you can improve the optical effect of the print still further as well as increasing its mechanical stability. The micro-porous surface engineering allows you to finish the product quickly e.g. by cutting to size and applying. The ink must be completely dry before lamination

euromedia BigPicture Photopaper 200 gloss wb

Product Properties

Applications

- indoor

Properties

- cold lamination
- heat lamination
- PVC-Free

Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



Specifications

Material	Paper
Ink	Waterbased inks
Whiteness	L* 92.2 (+/-5) a* -0.4 (+/-0.3) b* -2.4 (+/-0.5) delta b 10.8 (+/-0.8)
Total thickness	202 mic +/-5 mic
Weight	198g/m ² +/-7 g/m ²
Opacity	> 86%

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
Heesenstraße 31 40549 Düsseldorf DE
Tel: +49 211-5089-326
Fax: +49 211-5089-287
grafische_systeme@fujifilm.de