

Roll-up systems, banners, indoor  
tensioned coverings



Textiles

## euromedia BlockOut Textile FR

Smart blackout textile with B1 for roll-up graphics printed using solvent-based inks. Totally reflection-free, matt white surface with a special polymer coating for saturated prints with low ink consumption. Convincing textile structure.

BlockOut Textile FR is a PVC-free polyester textile, making it particularly environmentally friendly. Further benefits of polyester are: High tear resistance, dimensional stability and lie-flat properties. The grey blackout coating on the reverse provides 100% opacity, even with demanding lighting situations from the back.

### Dimensions

340g - 1030mm(40') - 30m  
340g - 1520mm(60') - 30m

### Product Code

70100110427  
70100110509



### Hints & Tips

Simply use euromedia Fabric Bond to bond BlockOut Textile FR for mounting a number of graphics vertically or producing hollow seams

## euromedia BlockOut Textile FR

### Product Properties

#### Applications

- indoor
- displays
- banners

#### Properties

- OEKO-TEX
- PVC-Free
- fire classification B1
- Blockout

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

Material	PES
Ink	Solvent, Latex, UV
Flame retardancy	B1 (DIN 4102)
Whiteness	> 150%
Total thickness	0,40 mm +- 0,03 mm
Weight	340 g/m² +-20 g/m²
Yarn	34/4/ /34/1 Nm
Tearing Strength	> 20/18 N

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
Heesenstraße 31 40549 Düsseldorf DE  
Tel: +49 211-5089-326  
Fax: +49 211-5089-287  
grafische\_systeme@fujifilm.de