

Adhesive film for applying prints onto glass and acrylic panels or lightboxes



Double sided self adhesive

euromedia OptiClear UV Mountingfilm

Double-sided self-adhesive, highly transparent film with UV protection for applying prints to glass and acrylic panels or lightboxes. For indoor and outdoor applications. Permanent adhesive on one side (for applying the print) and removable, solvent-based acrylic adhesive on the other (for application to glass, for example). The carrier material between the two adhesive layers is made of polypropylene.

euromedia OptiClear UV Mountingfilm gives you the chance to make everything self-adhesive including even the print side! Laminating with OptiClear UV Mountingfilm increases colour brilliance. The print is also protected from creases, moisture, water and abrasion. The UV protection ensures that the colours of your print are protected from fading over a long period. The removable side is on the inside of the roll and the permanent adhesive side on the outside.

Dimensions

30mic - 1050mm(41') - 50m
30mic - 1530mm(60') - 50m

Product Code

70100100096
70100112223



Hints & Tips

We recommend that you always apply the material dry. Wet application should only be undertaken if the user can ensure that the water (without soap) is completely removed using a squeegee. If the water is not completely removed, the adhesive may oxidise! Please note that wet application can only be undertaken at your own risk, as we recommend only dry application. This material is stabilized with plastic caps. Please use the original packaging for storage

euromedia OptiClear UV Mountingfilm

Product Properties

Applications

- indoor
- outdoor
- citylights/backlights



Properties

- PVC-Free
- transparent

Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.

Specifications

Material	Polypropylene
Surface	Transparent
Thickness	Substrate: 30mic
Liner	Monosiliconised polyester
Liner/ Backing weight	42 g/m ²
Weight	Substrate: 27 g/m ²
Adhesive type	Solvent based permanent acrylic (both sides)
Adhesive strength	Front: 10N/25mm (after 10h) Back: 3N/25 mm (after 20h) (up to 6 weeks removable)
Application temperature	Min. 5°C
Shelf life	Up to 1 year

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
Heesenstraße 31 40549 Düsseldorf DE
Tel: +49 211-5089-326
Fax: +49 211-5089-287
grafische_systeme@fujifilm.de