

Advertising on smooth and structured, flat and slightly curved areas. Appliances/casings, furniture, white goods and other objects in the POS segment (indoor)



Self-Adhesive indoor

## euromedia RigiTack FR wb

Exclusive to euromedia -Highly innovative product solution! Water-based printable, matt white rigid PVC. Adheres to flat and structured surfaces; may be repeatedly re-positioned.

RigiTack FR wb is extremely dimensionally stable as is very simple to apply, even for the inexperienced user. If instead you are looking for a material for durable outdoor applications, we'd be happy to tell you about euromedia WonderVinyl FR wb!

### Dimensions

360my - 1040mm(41') - 25m

### Product Code

70100109183



### Hints & Tips

Wear simple cotton gloves when handling print media and applying the finished graphics to keep you fingerprint safe

## euromedia RigiTack FR wb

### Product Properties

#### Applications

- indoor
- trade fairs

#### Properties

- removable adhesive
- fire classification B1

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

Material	Rigid PVC
Ink	Waterbased inks
Total thickness	370 mic
Adhesive type	Polyacrylic adhesive, removable
Adhesive weight	35g/m <sup>2</sup>
Temperature resistency	-30°C to +70°C
Application temperature	from 15° C
Shelf life	Up to 3 years

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
 Heesenstraße 31 40549 Düsseldorf DE  
 Tel: +49 211-5089-326  
 Fax: +49 211-5089-287  
 grafische\_systeme@fujifilm.de