

Transparent mounting film for fine art, posters, presentations of Kappa, Dibond etc



Double sided self adhesive

## euromedia Universal Mountingfilm

The nice and simple product solution: double-sided, permanent self-adhesive polypropylene film use where you want to mount long-lasting graphics on a carrier panel. Universal Mountingfilm is easy and clean to use and offers reliable adhesion by means of an environmentally friendly acrylic adhesive.

The neatest way of doubling your number of media by having an SA version of each. If you intend to apply your graphics behind glass, we recommend OptiClear highly transparent crystal clear mounting film with one permanent and one removable layer of adhesive.

### Dimensions

50mic - 1040mm(41') - 50m  
 50mic - 1370mm(54') - 50m  
 50mic - 1550mm(61') - 50m

### Product Code

70100098242  
 70100098433  
 70100098245



### Hints & Tips

First apply the graphics with just a little pressure to adhere lightly to the carrier panel. Only squeegee on, once the position is correct

## euromedia Universal Mountingfilm

### Product Properties

#### Applications

- indoor
- outdoor

#### Properties

- PVC-Free
- permanent adhesive

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

Material	Clear Polypropylene
Thickness	50 mic
Adhesive type	Water-based acrylic
Adhesive strength	10 min: > 5,0 / 24h: > 7,5 [N/25 mm]
Application temperature	15°C to 40°C

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
 Heesenstraße 31 40549 Düsseldorf DE  
 Tel: +49 211-5089-326  
 Fax: +49 211-5089-287  
 grafische\_systeme@fujifilm.de