

Print, fold, hang picture and frame in one for high quality advertising and decoration



Interior Design

## euromedia DecoFrame uv

The euromedia DecoFrame uv offers you picture and frame in one. Print using digital UV flatbed printers directly onto the board, whose high quality surface promotes the intense colours of your graphics. A few simple folds and the pre-perforated and self-adhesive DecoFrame is assembled into a finished three-dimensional picture, which can be hung straight away thanks to the ready-made hanger.

A stylish yet highly robust lightweight frame that can be assembled quickly and professionally, even by inexperienced users. No additional tools are required. In addition to its outstanding appearance, the flat sheets of the DecoFrame also make it a space-saver before and after printing and keep down transport costs. Print, fold, hang it couldn't be simpler! See the printing and assembling of a euromedia DecoFrame uv by Fujifilm. Watch the video.

### Dimensions

Print measure WxH: 495 mm x 595 mm - 10 pieces

### Product Code

70100109727



### Hints & Tips

Make the most of it: After direct printing on a UV flatbed printer such as the Acuity Advance from Fujifilm, finish the DecoFrame uv by screen printing unique effects that will capture everyone's attention. Do you prefer a textile feel? Get hold of our Artist Canvas FR and stretch it in a stretcher frame. Measures: Basic measure WxH: 701mm x 801mm Print measure WxH: 495mm x 595mm (please make sure that an edge (horizontal and vertical) of 103mm is given on every side) Assembled measure WxHxD: 406mm x 508mm x 38mm Please click here for the assembling instructions

## euromedia DecoFrame uv

### Product Properties

#### Applications

- indoor
- art

#### Properties

- PVC-Free

#### Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

#### Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



#### Specifications

Material	Self-adhesive board
Ink	UV
Surface	White
Gloss Level	Satin matt
Weight	180 g/m <sup>2</sup>

#### Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

**euromedia**

#### FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH  
Heesenstraße 31 40549 Düsseldorf DE  
Tel: +49 211-5089-326  
Fax: +49 211-5089-287  
grafische\_systeme@fujifilm.de