

Wall and interior design, trade fair panels, photo wallpapers, indoor



Interior Design

euromedia SmoothWall FR

Genuine Erfurt fleece wallpaper for modern applications using solvent, UV or latex printing. Plain, smooth surface with a special finish for almost photo-realistic image reproduction. Easy to use and apply with common fleece pastes. Manufactured by Erfurt & Sohn. New: The new homogeneous surface of Smooth Wall FR is smoother and weighs now 210gram. This allows to stick and handle the material much better.

Robust euromedia SmoothWall FR is PVC-free, which makes it extremely environmentally friendly. Thanks to its DIN EN 13501 flame-retardant certification, there are no limits to its use indoors. The perfect requirement for trade fairs. The special coating guarantees very good printability. Its excellent dimensional stability makes butted application easy producing clean results. Wallpapers can then be removed later dry and without leaving a residue.

Dimensions

210g - 0750mm(30') - 40m

210g - 1500mm(59') - 50m

Product Code

70100109205

70100109361



Hints & Tips

Individual prints on canvas are also highly fashionable so that you might also be successful in appealing to the smaller purse, we recommend you use the new euromedia Color Canvas wb with its sky-high performance and rock-bottom price.

euromedia SmoothWall FR

Product Properties

Applications

- indoor
- art
- trade fairs

Properties

- PVC-Free
- fire classification B1
- cold cutting
- can be pasted

Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

When using Latex inks of first generation (L789, LX600, LX800) a reduced water- and abrasion resistance of the print can appear.

Storage

The product should be stored in its original packaging at a room temperature of 15°C - 25°C and 40 - 60% relative humidity.



Specifications

Material	Fleece Wallpaper
Ink	Solvent, Latex, UV
Flame retardancy	B1
Gloss Level	Smooth
Weight	210 g/m ²
Others	Water-vapour permeability in accordance with DIN: 0,05

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
 Heesenstraße 31 40549 Düsseldorf DE
 Tel: +49 211-5089-326
 Fax: +49 211-5089-287
 grafische_systeme@fujifilm.de