

For adhesive-free wall and room designs, trade-fair panels, indoor photo-wallpaper



Interior Design

euromedia SmoothWall II sticky

The clean solution! Pressure sensitive non-woven wallpaper for shortterm applications like trade fairs and shop design Plain, smooth surface with special finish for near-photographic reproductions. Easy handling, clean & problem-free hanging without pasting or soaking.

euromedia SmoothWall II sticky is a robust and 100% PVC-free wallpaper suitable for indoor use. Perfect printability and self-adhesive reverse side make for even easier processing than with previous fleece wallpapers. In addition, it can be removed dry for up to 4 weeks without any residue. The latest interior decoration trends go for customized prints on canvas to lure even customers on a budget, we recommend euromedia Color Canvas wb, perfect on stretcher frames: strikingly superior performance at down to earth prices.

Dimensions

180g - 0750mm(30') - 40m

Product Code

70100110677



Hints & Tips

Please note that SmoothWall II sticky can only be conditionally recommended for Latex inks. Individual test is recommended

euromedia SmoothWall II sticky

Product Properties

Applications

- indoor
- trade fairs
- application on flat surfaces

Properties

- PVC-Free
- semi-permanent adhesive

Processing Tips

We basically recommend that the print is left to dry out for 24 hours before finishing.

The surface needs to be clean and free from any dirt, oil or other pollution prior application.

SmoothWall II sticky is suitable for smooth surfaces, like for example exhibition panels or non-absorbent surfaces.

Adhesive residue might occur on PVC surfaces.

We recommend storing the material in the original case. Store the rolls always together with the label and batch number. Without batch number, no claims can be accepted.

When using Latex inks of first generation (L789, LX600, LX800) a reduced water- and abrasion resistance of the print can appear.

Storage

The product should be stored in its original packaging at a room temperature of 18°C - 25°C and 40 - 65% relative humidity.



Specifications

Material	Fleece Wallpaper
Ink	Solvent, Latex, UV
Gloss Level	Smooth
Weight	180 g/m ²
Adhesive type	Semi-permanent
Adhesive strength	after 10 min. > 2,0 N/25 mm after 24h > 7,0 N/25 mm (AFERA 4001)
Temperature resistency	-30°C to 50°C
Shelf life	Up to 1 year

Note

This information relates to the current state of our knowledge and is given without obligation to provide you with information about our products and their applications. The information we give does not absolve you from carrying out your own trials and tests of the suitability of our products for your intended application. We reserve the right to carry out modifications, which will result in an improvement to the product.

euromedia

FUJIFILM Deutschland

Niederlassung der FUJIFILM Europe GmbH
Heesenstraße 31 40549 Düsseldorf DE
Tel: +49 211-5089-326
Fax: +49 211-5089-287
grafische_systeme@fujifilm.de